
Electrolux

Libretto d'istruzione e uso
Notice d'instructions et mode d'emploi
Instruction manual
Bedienungsanleitung
Manual de uso y manutencion
Gebruiksaanwijzing
Livro de instrucçoes e modo de emprego
Instrukcja obsługi i konserwacji
Használati utasítás
Návod k používání
Brugsvejledning
Bruksanvisning
Bruks- og vedlikeholdsveiledning
Käyttöohjeet
Navodila za uporabo in vzdrževanje
Εγχειρίδιο οδηγιών χρήσης



Rasaerba con motore a scoppio - Lama 47 cm

Tondeuse avec moteur thermique - Lame 47 cm.

Lawn mower with petrol engine - 47 cm blade

Rasenmäher mit Explosionsmotor - Messer 47 cm

Cortadora de hierba con motor de explosión – Cuchilla 47 cm.

Grasmaaimachine met verbrandingsmotor – Mes 47 cm.

Cortagrama com motor a explosão – Lamina 47 cm.

Kosiarka do trawy z silnikiem gazowym – Noż 47 cm.

Robbanò-motor hajtàsù fûnyíró - Kès 47 cm

Sekačka na trávu se spalovacím motorem – žací nůž 47 cm

Plæneklipper med benzinmotor – 47 cm klinge

Gräsklippare med bensinmotor - Kniv 47 cm

Gressklipper med bensinmotor - 47 cm kniv

Polttomoottorilla varustettu ruohonleikkuri – Terä 47 cm


Motorna kosilnica – rezilo 47 cm.

Χλοοκοπτική μηχανή με κινητήρα εσωτερικής καύσης - Μαχαίρι 47 cm.




Rasaerba a spinta
Tondeuse poussée
Manual lawn mower
Rasenmäher-Schiebegerät
Cortadora de hierba de empuje
Handmaaimachine
Cortagrama de empurro
Kosiarka do trawy
Tolòfûnyìrò

Sekačka na trávu bez pojezdu
Plæneklipper med Benzinmotor
Gräsklippare utan drivning
Gressklipper uten drift
Työnnettävä ruohonleikkuri
Ročna kosilnica
Χλοοκοπτική μηχανή με ώθηση



Rasaerba semovente
Tondeuse tractée
Self-propelled lawn mower
Selbstfahrender Rasenmäher
Cortadora de hierba propulsada
Zelfrijdende grasmaaimachine
Cortagrama semovente
Kosiarka do trawy samobieżna

Önjàrò- fûnyíró
Sekačka na trávu s pojezdem
Selvkørende plæneklipper
Självgående gräsklippare
Gressklipper med drift
Vetävä ruohonleikkuri
Kosilnica na avtomatski pogon
Αυτοκίνητη χλοοκοπτική μηχανή



Rasaerba semovente 3 velocità
Tondeuse tractée à 3 vitesses
3-speed self-propelled lawn mower
Selbstfahrender 3-Gang-Rasenmäher
Cortadora de hierba propulsada 3 velocidades
Zelfrijdende grasmaaimachine 3 snelheden
Cortagrama semovente tre velocidades
Kosiarka do trawy samobieżna o 3 prędkościach
Önjàrò - fûnyíró 3 sebessègfokozattal
Sekačka na trávu s 3 rychlostmi pojezdu
Selvkørende plæneklipper med 3 hastigheder
Självgående gräsklippare med 3 hastigheter
Gressklipper med drift, 3 hastigheter
Vetävä 3- nopeuksinen ruohonleikkuri
Kosilnica na avtomatski pogon3 hitrosti
Αυτοκίνητη χλοοκοπτική μηχανή με 3 ταχύτητες



Rasaerba semovente con freno lama
Tondeuse tractée avec frein lame
Self-propelled lawn mower with blade brake
Selbstfahrender Rasenmäher mit Messerbremse
Cortadora de hierba propulsada con freno cuchilla
Zelfrijdende grasmaaimachine met mesrem
Cortagrama semovente com freio lamina
Kosiarka do trawy samobieżna z hamulcem ostrza
Önjàrò - fûnyíró kèsfèkkel
Sekačka na trávu s brzdou žacího nože
Selvkørende plæneklipper med klingebremse
Självgående gräsklippare med broms för kniven
Gressklipper med drift og knivclutch
Vetätä ruohonleikkuri teräjarrulla
Kosilnica na avtomatski pogon z rezilom na zavoro
Αυτοκίνητη χλοοκοπτική μηχανή με φρένο μαχαιριού



Rasaerba semovente 3 velocità con freno lama
Tondeuse tractée à 3 vitesses avec frein lame
3-speed self-propelled lawn mower with blade brake
Selbstfahrender 3 Gang-Rasenmäher und Messerbremse
Cortadora de hierba propulsada 3 velocidades con freno cuchilla
Zelfrijdende grasmaaimachine 3 snelheden met mesrem
Cortagrama semovente tre velocidades com freio lamin
Kosiarka do trawy samobieżna o 3 prędkościach z hamulcem ostrza
Önjàrò - fûnyíró 3 sebessègfokozattal kèsfèkkel
Sekačka na trávu s 3 rychlostmi pojezdu a brzdou žacího nože
Selvkørende plæneklipper med 3 hastigheder og klingebremse
Självgående gräsklippare med 3 hastigheter och broms för kniven
Gressklipper med drift, 3 hastigheter og knivclutch
Vetävä 3 - nopeuksinen ruohonleikkuri teräjarrulla
Kosilnica na avtomatski pogon s 3 hitrosti in rezilom na zavoro
Αυτοκίνητη χλοοκοπτική μηχανή με 3 ταχύτητες και φρένο μαχαιριού



Versione avviamento elettrico
Tondeuse démarrage électrique
Electric-starter lawn mower
Rasenmäher elektrischem Anlasser
Cortadora arranque eléctrico
Grasmaaimachine met elektrische ontsteking
Cortagrama acionamento elétrico
Kosiarka do trawy zapłon elektryczny

Villamos indìtàsù - fûnyíró
Sekačka na trávu s elektrickým startem
Plæneklipper med elektrisk start
Gräsklippare med elektrisk start
Gressklipper med drift og elektrisk start.
Vetävä ruohonleikkuri
Model na elektrièni pogon
Εκδοχή με ηλεκτρική εκκίνηση



Versione lusso
Version de luxe
Luxury version
Version Luxusausführung
Version lujo
Luxe grasmaaimachine
Cortagrama luxo
Kosiarka do trawy luksusowa

" Luxus " - fûnyíró
Sekačka na trávu-Luxusní verze
Luksus plæneklipper
Gräsklippare lyxversion
Luksus gressklipper.
Laadukas ruohonleikkuri
Luksuzni model
Εκδοχή πολυτελείας

Il presente manuale rappresenta una parte integrante del prodotto. Vi preghiamo di conservarlo per ogni ulteriore utilizzo.

Le manuel présent fait partie intégrante du produit; nous vous prions en conséquence de le conserver pour toutes nécessités ultérieures.

The present manual constitutes an integral part of the product and it should be kept for all future reference.

Das vorliegende Handbuch gehört zu einem festen Bestandteile des Produktes und muss deshalb zur Einsichtnahme sorgfältig aufgehoben werden.

El presente manual representa una parte integrante del producto. Les rogamos que lo conserven para cualquier ulterior empleo.

Deze handleiding is een integrerend deel van het product. Wij verzoeken u hem te bewaren voor iedere mogelijke nadere raadpleging

Este manual representa uma parte integrante do produto. Recomendamos guardá-lo para outros usos.

Niniejsza instrukcja stanowi integralną część produktu. Prosimy przechowywać ją do kazédego dalszego uzytkowania.

A jelen szakkönyv a termék szerves részét képezi. Kérjük megörizni minden utólagos használatért.

Tato uživatelská príručka je neopomenutelnou součástí výrobku. Uschovejte ji pro další použití.

Håndbogen er en integreret del af produktet. Den skal opbevares omhyggeligt for yderligere konsultation.

Denna manual utgör en integrerande del av produkten. Vi ber er spara den för senare bruk.

Dette håndboken representerer en fullende del av produkten. Det skal oppbevares for alle ytre anvendelser.

Tämä käyttöopas kuuluu olennaisena osana tuotteeseen. Säilytä se huolellisesti myöhempää käyttöä varten.

Navodila za uporabo in vzdrževanje so sestavni del izdelka, zato prosimo, da jih shranite in upoštevate za nadaljnjo uporabo.

Το παρόν εγχειρίδιο αποτελεί ενα ολοκληρωτικό μέρος του προιόντος. Σας παρακαλούμε να το φυλάξετε με προσοχή για κάθε περαιτέρω χρήση.

I

F

GB

D

E

NL

P

PL

H

SK

CZ

DK

S

N

SF

SLO

GR

La ringraziamo per la fiducia accordataci con l'acquisto del nostro rasaerba. Siamo certi che avrà modo di apprezzare nel tempo e con soddisfazione la qualità del nostro prodotto. La preghiamo di leggere attentamente questo manuale predisposto appositamente per informarla circa il suo uso corretto in conformità ai requisiti essenziali di sicurezza.

Nous vous remercions de la préférence que vous nous avez accordée en choisissant notre tondeuses. Nous sommes persuadés que vous pourrez apprécier dans le temps la qualité de notre produit et que vous en serez entièrement satisfaits.Nous vous prions de lire attentivement ce manuel, spécialement conçu pour illustrer l'utilisation correcte de cette machine, dans le respect des normes de sécurité fondamentales.

We wish to thank you for choosing our lawn mowers. We are confident that the high quality of our machine will meet with your satisfaction and appreciation and that your lawn mower will give you long-lasting service.Before starting to use your machine, make sure to read with care this manual, which has been purposely drawn up to provide you with all the necessary information for proper use, in compliance with basic safety requirements.

Wir danken Ihnen für Ihr Vertrauen, das Sie uns durch den Kauf unseres Rasenmäher entgegengebracht haben und sind sicher, daß Sie mit der Qualität unseres Produkte zufrieden sein werden.Wir bitten Sie, dieses Handbuch aufmerksam durchzulesen, das Sie über die richtige Verwendung in Übereinstimmung mit den Sicherheitsvorschriften informiert.

Le damos las gracias por la confianza que nos ha demostrado al comprar nuestro cortacesped. Estamos seguros de que podrá apreciar con el tiempo y con satisfacción la calidad de nuestro producto.Le rogamos lea atentamente este manual preparado expresamente para informarle sobre el uso correcto con arreglo a los requisitos básicos de seguridad.

Wij danken u voor het vertrouwen waarmee voor u onze maaimachine heeft gekozen.
U zult langduriq plezier hebben van de kwaliteit van dit produkt.
Leest u aandachtig dit handboek, dat speciaal bedoeld is om u te informeren over het juiste gebruik ervan volgens de vereiste veiligheidsvoorwaarden.

Agradecemos a preferência que nos deram, escolhendo a nossa cortadores de relva.Estamos seguros que, com o tempo, podereis apreciar a qualidade dos nossos produtos e ficareis plenamente satisfeitos.
Pedimos a leitura atenta deste manual, preparado especialmente para informar da utilização correcta da máquina e das normas de segurança fundamentais.

Gratulujemy Państwu zakupu naszej kosiarka do trawy jesteśmy pewni, zée będziecie Państwo usatysfakcjonowani wysoką jakoscią naszego produktu.
Prosimy o uważne przeczytanie całej instrukcji obsługi i szczegółowe zapoznanie się ze wskazaniami dotyczącymi bezpieczenstwa użytkowania urządzenia.

Köszönjük Fűnyírógép megvásárlása útján belénkhelyezett bizalmat. Biztosak vagyunk, hogy meg lesz elégedve gyártmanyunk minőségével. Kérjük, olvassa el figyelemmel ezt az utasítást a helyes használati mod és a biztonsági eloirások betartása érdekében.

Děkujeme za Vaši důvěru, kterou jste projevili nákupem naší sekačky na trávu. Jsme přesvědčeni, že vysoká kvalita našich výrobků splní Vaše očekávání a sekačka Vám bude spolehlivé sloužit po dlouhou dobu. Než sekačku nastartujete, přečtěte si pozorně tento návod k používání, který Vám poskytne všechny nezbytné informace týkající se použití stroje v souladu se základními bezpečnostními předpisy.

Vi takker dig for at have valgt en af vores plæneklippere. Vi er overbeviste om, at maskinens høje kvalitet og præstationer vil tilfredsstille dine forventninger og klippe din plæne lang tid fremover. Læs vejledningen grundigt igennem, da den indeholder vigtige råd til en korrekt anvendelse i overensstemmelse med de vigtigste sikkerhedskrav.


Vi tackar er för det förtroende ni visat oss genom att köpa vår gräsklippare. Vi är övertygade om att ni med tillfredsställelse kommer att uppskatta vår produkts kvalitet under en lång tid framöver. Vi ber er att noggrannt läsa denna bruksanvisning som har till uppgift att informera er om hur man ska använda gräsklipparen på ett korrekt sätt i enlighet med nödvändiga säkerhetskrav.

Takk for tilliten du har vist ved å kjøpe vår gressklipper. Vi er sikker på at du i fremtiden vil sette pris på og ha glede av kvaliteten til vårt produkt. Vi ber deg om å lese denne veiledningen for å få all informasjon om riktig bruk i overensstemmelse med de viktigste sikkerhetskravene.

Kiitämme ruohonleikkurimme valinnasta. Olemme varmoja, että tuotteemme tarjoaa parhaan mahdollisen suorituskyvyn ja kestää käytössä pitkään. Lue käyttöopas huolellisesti, sillä se antaa tärkeää laitteen oikeaan ja turvalliseen käyttöön liittyvää tietoa.

Spoštovani kupec, zahvaljujemo se Vam za nakup enega naših proizvodov in Vam želimo veliko zadovoljstva pri delu z novo kosilnico.
Preden pričnete z uporabo kosilnice, pozorno preberite navodila, predstavljena v tem priročniku, da bi spoznali in razumeli njegovo vsebino glede pravilne uporabe kosilnice in temeljnih varnostnih ukrepov pri delu.

Σας ευχαριστούμε για την προτίμηση που μας δείξατε αγοράζοντας την χλοοκοπτική μας μηχανή. Είμαστε βέβαιοι οτι χρησιμοποιώντας την θα μπορέσετε να εκτιμήσετε με ευχαρίστηση την ποιότητα του προϊόντος μας. Σας παρακαλούμε να διαβάσετε προσεκτικά το εγχειρίδιο αυτό που συντάχθηκε επίτηδες για να Σας πληροφορεί κατά σωστό τρόπο όσον αφορά την σωστή χρήση της μηχανης σύμφωνα με τους βασικούς κανόνες ασφαλείας.



1

Attenzione! *Leggere il manuale di istruzioni prima dell'uso*
Attention! *Lire le manuel d'instructions avant utilisation.*
Caution! *Read the instruction manual before use.*
Achtung! *Vor der Verwendung ist die Bedienungsanleitung zu lesen.*

Atención! *Leer el manual de instrucciones antes del uso.*
Pas op! *De gebruiksaanwijzing voor het gebruik nauwkeurig doorlezen.*
Atenção! *Ler o manual de instruções antes do uso.*
Uwaga! *Przed użyciem przeczytać instrukcję obsługi.*

Figyelem! *Elolvasni az utasìtàsokat a hasznàlat elott.*
Upozornění! *Než začnete sekačku používat, pozorně si prostudujte návod k používání.*
Forsigtig! *Læs vejledningen igennem inden ibrugtagning.*
Varning! *Läs bruksanvisningen innan ni använder gräsklipparen*

Advarsel! *Les bruksveiledningen før bruk.*
Huomio! *Lue käyttöopas huolellisesti ennen laitteen käyttöönottoa.*
Pozor! *Pozorno preberite navodila preden pričnete z uporabo kosilnice.*
Προσοχή! *Διαβάστε προσεκτικά το εγχειρίδιο οδηγιών πρίν απο την χρήση.*

2

Tenere le persone estranee fuori dalla zona di pericolo!
Eloigner toute personne etrangère de la zone dangereuse!
Keep other people well away from the danger area!
Unbefugte dürfen nicht in den Gefahrenbereich gelangen!

Mantener al personal ajeno fuera de la zona de peligro!
Zorg ervoor dat andere personen buiten de gevarenzone blijven!
Manter pessoas estranhas fora da zona de perigo
Osoby postronne nie powinny przebywac w zasięgu pracy urządzenia.

A veszélyes területen ne tartózkodjanak idegenek!
V nebezpečné vzdálenosti se nesmí zdržovat cizí osoby!
Hold uvedkommende personer på sikker afstand af farezonen!
Håll alla obehöriga på avstånd från riskområdet!

Hold uvedkommende utenfor faresonen!
Älä anna asiattomien henkilöiden oleskella vaara-alueella!
Oddaljite tuje osebe iz delovnega območja kosilnice!
Απομακρύνετε τα άσχετα πρόσωπα απο τον χώρο κινδύνου.

3

Attenzione*:pericolo ferimento mani e piedi.*
Attention! *Danger de blessures des mains et des pieds.*
Warning*: Risk of hand and feet injury.*
Achtung*: Hand- und Fussverletzung*

Atención*: peligro heridas a manos y pies.*
Let op, *gevaar voor verwondingen aan handen en voeten.*
Atenção, *perigo machucamento mãos e pés.*
Uwaga, *wirujący nóż niebezpieczenstwo zranienia rąk i nóg.*

Figyelem, *veszèly: kezek ès làbak megsebzèse.*
Pozor*, nebezpečí poranění rukou a nohou.*
Forsigtig: *Fare for tilføjelse af sår på hænder og fødder.*
Varning*: risk för skada på händer och fötter.*

Advarsel: *Fare for å skade hendene og føttene.*
Huomio*: käsien ja jalkojen loukkaantumisen vaara.*
Pozor! *Nevarnost poškodb rok in nog!*
Προσοχή! *Κίνδυνος τραυματισμού χεριών και ποδιών.*

4

Pericolo di aspirazione di gas tossici! Non utilizzare l'apparecchio in ambienti chiusi o poco ventilati.
Danger d'inhalation de gaz toxiques! Ne pas utiliser l'appareil dans des espaces fermés ou peu ventilés.
Risk of breathing in toxic gases ! Do not use the appliance in closed or poorly ventilated environments.
Gefahr des Einatmens giftiger Gase ! Das Gerät darf nicht in geschlossenen oder schlecht belüfteten Räumen verwendet werden.

Peligro de aspiración de gases tóxicos! No utilizar el aparato en ambientes cerrados o poco ventilados.
Gevaar voor inademing van giftige gassen! Gebruik het apparaat niet in gesloten of niet goed geventileerde ruimtes.
Perigo de aspiração de gás tossicos! Não utilizar o aparelho em lugares fechados ou pouco ventilados.
Niebezpieczenstwo wdychania gazów trujących! Nie uzywac urządzenia w pomieszczeniach zamkniętych lub o słabym przewietrzeniu.

Mèrgezo gàzak belègzèse veszèly! Ne hasznàlni a gèpet zàrt vagy kevèsbè szelloztetett helysègekben.
Nebezpečí vdechování toxických plynů! Výrobek nesmí být používán v uzavřených nebo nedostatečně větraných prostorách.
Fare for indånding af giftige gasser! Anvend andrig maskinen i lukkede eller dårligt ventilerede rum.
Risk för inandning av giftiga gaser! Använd inte apparaten i stängda eller dåligt ventilerade lokaler.

Fare for å puste inn giftige gasser! Ikke bruk apparatet i lukkede eller dårlig ventilerte lokaler.
Myrkyllisten kaasujen hengittämisen vaara! Älä käytä laitetta suljetuissa tai riittämättömästi ilmastoiduissa tiloissa.
Nevarnost vdihavanja strupenih izpušnih plinov! Nikoli ne uporabljajte kosilnice v zaprtem ali slabo zracenem prostoru.
Κίνδυνος εισπνοής τοξικών αερίων. Μη χρησιμοποιείτε την συσκευή σε κλειστους ή λίγο αεριζόμενου χώρους.

5

Pericolo di esplosione! *Non effettuare rabbocchi di carburante con motore in moto.*
Danger d'explosion ! *Ne pas faire le plein de carburant, moteur en marche.*
Risk of explosion ! *Do not top up with fuel with engine running.*
Explosionsgefahr ! *Treibstoff darf nicht bei laufendem Motor nachgefüllt werden.*

Peligro de explosión! *No rellenar con carburante cuando el motor está encendido*
Gevaar voor explosie! *Vul geen brandstof met draaiende motor bij.*
Perigo de explosão! *Não juntar o carburante com o motor em função*
Niebezpieczeństwo wybuchu! *Nie przelewać paliwa przy zapalonym silniku*

Robbanàsveszèly! *Ne hajtani vègre az uzemanyag toltèst amikor a motor mukodèsben van.*
Nebezpečí výbuchu! *Pohonné hmoty je zakázáno doplňovat pokud je motor v chodu.*
Eksplosionsfare! *Fyld aldrig brændstof på med motoren tændt.*
Risk för explosion! *Utför inte påfyllning av bränsle med motorn igång.*

Fare for eksplosjon! *Ikke etterfyll drivstoff med motoren i gang.*
Räjähdyksen vaara! *Älä suorita polttoaineentäydennystä moottorin käydessä.*
Nevarnost eksplozije! *Ne nalivajte gorivo v kosilnico, ko motor deluje.*
Κίνδυνος έκρηξης! *Μη βάζετε τα καύσιμα με τον κινητήρα υπο κίνηση.*

6

Attenzione! *Superficie calda.*
Attention! *Surface chaude*
Caution! *Hot surface*
Achtung! *Oberfläche ist heiß.*

Atención! *Superficie caliente*
Pas op! *Warm oppervlak*
Atenção! *Supercifie quente*
Uwaga! *Powierzchnia gorąca*

Figyelem! *Meleg felulet.*
Výstraha! *Horký povrch.*
Forsigtig! *Varm overflade.*
Varning! *Mycket het yta.*

Advarsel! *Varm overflate*
Huomio! *Kuuma pinta.*
Pozor! *Vroca površina.*
Προσοχή! *Επιφάνεια θερμή.*

7

Attenzione! *Spegnere il motore e staccare la candela prima di effettuare qualunque manutenzione*
Attention! *Eteindre le moteur et enlever la bougie avant d'effectuer quelque opération d'entretien que ce soit.*
Caution! *Switch off the engine and disconnect the spark plug before undertaking any maintenance work.*
Achtung! *Vor der Ausführung jeglicher Wartungsarbeiten ist der Motor abzuschalten und die Zündkerze abzuklemmen.*

Atención! *Apagar el motor y extraer la bujía antes de efectuar cualquier manutención*
Pas op! *De motor uitzetten en de bougie ontkoppelen alvorens enige onderhoudshandeling uit te voeren.*
Atenção! *Desligar o motor e a vela antes de qualquer manutenção*
Uwaga! *Przed wykonaniem jakiejkolwiek konserwacji zgasic silnik zdjąć przewód ze świecy*

Figyelem! *Kikapcsolni a motrot ès kiiktatni a gyertyàt minden karbantartàsi muvelet elott.*
Výstraha! *Před zahájením jakékoli údržby stroje vypněte motor a odpojte kabel ze zapalovací svíčky.*
Forsigtig! *Enhver form for vedligeholdelse skal ske med slukket motor og frakoblet tændrør.*
Varning! *Stäng av motorn och lossa tändstiftet innan något som helst ingrepp för underhåll utförs.*

Advarsel! *Slå av motoren og kople fra tennpluggen før det utføres vedlikehold.*
Huomio! *Sammuta moottori ja irrota sytytystulppa ennen minkään huoltotoimenpiteen aloittamista.*
Pozor! *Ugasnite motor in snemite kabel s sveèke pred kakršnemkoli vzdrzevalnem delu*
Προσοχή! *Σβήνετε τον κινητήρα και αποσυνδέετε το μπουζί προτού κάνετε οποιαδήποτε επέμβαση συντήρησης.*

8

Tenere il cavo di alimentazione lontano dall'utensile tagliente.
Ecarter le câble d'alimentation de l'outil tranchant.
Keep the power supply cable well away from the cutting tool.
Das Speisekabel darf nicht in den Bereich des Schneidwerkzeuges gelangen.

Mantener el cable de alimentaciòn lejos de la herramienta de corte,
De voedingskabel op afstand van de maairichting houden.
Manter pessoas estranhas fora da zona de perigo.
Przewód zasilający nie może znajdować się w zasięgu pracy noża.

A veszlyes területen ne tartózkodjanak idegenek!
Zákaz zdrziavania sa cudzích osôb v nebezpecnej oblasti.
Strømtilførselskablet må ikke være i nærheden af skæreredskabet.
Håll matningskabeln på säkert avstånd från klippningsverktyget.

Hold strømkabel i god avstand fra kniven.
Pidä virtajohto kaukana leikkaavasta terästä.
Vedno ohranite razdaljo med elektricnim kablom in rezilom.
Κρατάτε το τροφοδοτικό καλώδιο μακριά απο το κοφτερό εργαλείο.

9

Attenzione! *Proteggere dalla pioggia e dall'umidità.*
Attention! *Protéger de la pluie et de l'humidité.*
Caution! *Shelter from rain and humidity.*
Achtung! *Vor Regen und Nässe schützen.*

Atención! *Proteger de la lluvia de la humedad.*
Voorzichtig! *Beschermen tegen regen an vocht.*
Atenção! *Protegercontra a chuva e a humidade.*
UWAGA! *Zabezpieczyć przed deszczem i wilgocią.*

Figyelem! *Óvni az esőtől és a nedvességtől.*
POZOR! *Chraňte před deštěm a vlhkem.*
BEMÆRK!*Skal beskyttes mod regn og fugtighed*
Varning! *Skyddas från regn och fukt.*

Pas på! *Beskyttelse mot regn og fuktighet.*
Varoitus! *Suojele sateelta ja kosteudelta.*
Pozor! *Zaščitite pred dežjem in vlažnostjo.*
Προσοχη ! *Προστατευετε απο την βροχη και την υγρασια*

10

Prima di qualsiasi intevento sull'utensile tagliente togliere la spina di alimentazione
Déconnecter la fiche avant d'intervenir sur l'outil tranchant
Before carrying out any operations on the cutting tool, disconnect the plug
Vor jeglicher Arbeit am Schneidwerkzeug den Stecker abnehmen

Antes de intervenir en la herramienta de corte quitar la clavija
Voor alle onderhoudswerkzaamheden aan de snijinrichting de stekker uittrekken
Afastar o cabo de alimentação da parte de corte.
Przewód zasilający nie powiniwn znajdowac się w zasięgu pracy noza.

Elektromos kábelt a pengétől távoltartani
Elektrická šnúra musí byt' d'aleko od rezacieho nástroja.
Tag stikket ud af stikkontakten, inden der røres ved kniven.
Innan något som helst ingrepp på klippningsverktyget sker, tag ut kontakten för elektrisk matning.

Ta av tilføringstøpselen før alle inngrepene på verketøyet.
Irrota pistotulppa pistorasiasta ennen minkään leikkaavaan terään tehtävän toimenpiteen suorittamista.
Ugasnite motor in snemite električni kabel pred kakršnemkoli vzdr•evalnem delu.
Προτού κάνετε οποιαδήποτε επέμβαση στο κοφτερό εργαλείο βγάζετε το φις τροφοδοσίας.

A

DESCRIPTION *(starts at page 51)*

1	Upper handles	7	Deck	14	Engine stop lever
2	Lower handles	8	Adjusting levers for cutting height	15	Reduction gear
3	Fastening knobs for upper handles	9	Spark plug	16	Console
4	Grass catcher	10	Fuel cap	17	Ignition key
5	Oil filler cap	11	Engine start-grip	18	Clutch lever
6	Oil drain plug	12	Rear deflector	19	Blade engagement lever
		13	Throttle lever	20	Handle advance speed

B

ASSEMBLY OF GRASS CATCHER *(starts at page 51)*

C

ASSEMBLY REAR DEFLECTOR *(starts at page 51)*

D1

ASSEMBLY *(starts at page 52)*



Manual lawn mower

Remove the bail arms, attach cables as shown and re-fit the bail arms, if applicble.

Assemble the handle fit the levers with the pins and clips provided, assemble the wheels as shown and throttle if supplied.

D2

ASSEMBLY *(starts at page 53)*




Self-Propelled/ Electric Start Lawnmower.

Remove the bail arms, attach cables as shown and re-fit the bail arms.

D3

ASSEMBLY *(starts at page 54)*



3 Speed Self-Propelled/Electric Start Lawnmower.

Remove the bail arms, attach cables as shown and re-fit the bail arms.

D4

ASSEMBLY *(starts at page 55)*



Self-propelled Lawnmower with Blade Brake.

Remove the bail arms, attach cables as shown and re-fit bail arms.

D5

ASSEMBLY *(starts at page 56)*



3 Speed Self-Propelled Lawnmower with Blade Brake.

Remove the bail arms, attach cables as shown and re-fit the bail arms.

E

ADJUSTMENT OF CUTTING HEIGHT *(starts at page 57)*

F

SAFETY PRECAUTIONS *(starts at page 57)*

- Always operate with the deflector or grasscatcher in the correct position.
- Always stop the engine before removing the grasscatcher or adjusting the height of cut.
- Never place your hands or feet underneath the deck or into the rear grass discharge chute while the engine is running.

G

(starts at page 57)

Before mowing, remove all foreign objects from the lawn which may be thrown by the machine. While mowing, stay alert for any foreign objects which may have been missed.
Never lift the rear of the mower while starting the engine or during normal operation.

H

(starts at page 57)

Never place your hands or feet underneath the deck or into the rear discharge chute while the engine is running.

I

OPERATION *(starts at page 57)*

ENGINE ADJUSTMENTS

Refer to the engine manufacturer's maintenance manual.

CAUTION:- 0.6l Oil must be added to the engine before use.

J

(starts at page 57)

STARTING THE ENGINE

Once the machine has been set up properly, start the engine as follows:

a) *Engines with choke system:*
when the engine is cold, position the accelerator lever (13) on START

b)Operate the engine stop lever (14) to prepare the engine for start, keep lever pressed against handle while starting and using the machine - it operates the engine brake.

c) *Engines with primer system:*
Press the fuel-enrichment pump (Picture 'I' item 36) located on the carburettor 3 or 4 times position the accelerator lever (13) on MAX.

For further information and explanations, read carefully the user instruction manual of the engine.

K

(starts at page 57)

d) Start engine.

MANUAL STARTING: (While holding the engine stop lever (14)).

●Hold the engine start-grip (11) and pull the starter rope gently until you feel the resistance caused by compression. Return the starter rope slowly then pull the handle firmly towards you to its full extent.

L

(starts at page 57)

ELECTRICAL STARTING: (While holding the engine stop lever (14)).

●Insert the plug (G) in the socket (H) on the engine. Turn the ignition key (17).

CAUTION: *The blade starts turning as soon as the engine is started except on the BBC version.*

M



(starts at page 58)

Keep the engine stop lever (14) depressed during machine operation. When the lever is released, the engine stops.

MOWING

To cut the grass, push the lawn mower manually

N





(starts at page 58)

Keep the engine stop lever (14) depressed during machine operation. When the lever is released, the engine stops.

MOWING

To cut the grass, push the lawn mower manually or insert the automatic advance gear.

How to insert automatic advance: Lift up the clutch handle (18) and keep it pressed in position.

CAUTION: *Engage the gear only when the engine is running.*

How to disengage advance: Release the clutch handle.

O





(starts at page 58)

Keep the engine stop lever (14) depressed during machine operation. When the lever is released, the engine stops.

MOWING

To cut the grass, push the lawn mower manually or insert the automatic advance gear. Before proceeding with the coupling of the automatic feed, choose the speed by means of the change lever (20).

Change the speed with the clutch disengaged. There are 3 speed settings.

1°~ 0,6 m/s

2°~ 0,9 m/s

3°~ 1,2m/s

How to insert automatic advance: Lift up the clutch handle (18) and keep it pressed in position.

CAUTION: *Engage the gear only when the engine is running.*

How to disengage advance: Release the clutch handle.

P



(starts at page 58)

With engine running, pull the handle (14) towards the bar and keep depressed. Push the blade engagement lever (19) forward to make the blade rotate.

WARNING! *When the handle (14) is released the blade stops while the motor continues running.*

MOWING

To cut the grass, push the lawn mower manually or insert the automatic advance gear.

How to insert automatic advance: Lift up the clutch handle (18) and keep it pressed in position.

CAUTION: *Engage the gear only when the engine is running.*

How to disengage advance: Release the clutch handle.

Q



(starts at page 58)

With engine running, pull the handle (14) towards the bar and keep depressed. Push the blade engagement lever (19) forward to make the blade rotate.

WARNING! *When the handle (14) is released the blade stops while the motor continues running.*

MOWING

To cut the grass, push the lawn mower manually or insert the automatic advance gear. Before proceeding with the coupling of the automatic feed, choose the speed by means of the change lever (20).

Change the speed with the clutch disengaged. There are 3 speed settings.

1°~ 0,6 m/s

2°~ 0,9 m/s

3°~ 1,2m/s

How to insert automatic advance: Lift up the clutch handle (18) and keep it pressed in position.

CAUTION: *Engage the gear only when the engine is running.*

How to disengage advance: Release the clutch handle.

R

(starts at page 58)

Important: If, when you press the clutch lever, the automatic advance gear does not engage, the clutch cable should be adjusted by inserting the spring (P) in one of the subsequent holes in the plate (R) or in the hole "S" .

S

AUTOMATIC ADVANCEMENT *(starts at page 58)*

Periodically check the automatic advance assembly and make sure to keep it clean. In particular, the pinion (21) and the gear (22) must be kept perfectly clean. To carry out this check, you must remove the wheel (23) by unscrewing the screw (24).

SAFETY RULES

Training

a)Persons under 16 years of age and persons who are not familiar with the user instructions must not use the lawn mower.

b)The operator is responsible for the safety of other people in the working area. Keep children and domestic animals at a safe distance when the lawn mower is in use.

c)This machine is to be used exclusively for cutting natural grass. Never use the mower for other purposes (e.g., for flattening out bumps in the ground, such as mole-hills or ant- hills).

d)Work only when there is sufficient light.

e)Before mowing, remove all foreign objects from the lawn which may be thrown by the machine. While mowing, stay alert for any foreign objects which may have been missed.

Setting up and operating the lawn mower

a)When mowing, wear strong footwear (boots or heavy shoes) and long trousers.

b)Before you start mowing, make sure that the blade and blade fixing screw are securely fastened.
If the blade is damaged, it must be replaced.

c)Turn off the engine, wait until the blade has stopped and remove the spark plug cap before:

- transporting, lifting or moving the machine away from the working area;
- carrying out maintenance or cleaning, or when carrying out any operation on the blade;
- adjusting the cutting height;
- leaving the machine unattended.

Caution! The blade starts turning as soon as the engine is started

d)Caution! The fuel is highly inflammable:

- Store fuel in containers specifically designed for this purpose.
- Refuel outdoors only and do not smoke while refuelling.
- Fill up the fuel tank before starting the engine. Under no circumstances open the fuel tank cap or add petrol when the engine is running or when it is still hot.
- If the petrol has overflowed, do not under any circumstances start up the engine.Move the mower away from the area where fuel has bean spilt and avoid any source of possible ignition until the petrol fumes have dissipated.
- Replace the fuel tank cap and tighten it down firmly.

e)Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect..

f) When mowing, never run; you must always walk.

g)Exercise extreme caution when turning or when pulling the lawn mower towards you.

h)Particular precautions must be taken when mowing on slopes or downhill stretches:
- Use appropriate antislip footwear.
- Always be sure of your footing.
- Mow across the face of slopes, never up or down.
- Take great care when changing direction.
- Do not mow on excessively steep slopes.

i)Never use the lawn mower unless the guards and safety devices (e.g. deflector, grass catcher) are securely in position and in good condition.

j)Ensure that the grass catcher and deflector are correctly located. failure to do so may result in foreign objects being ejected by the blade.

k)For reasons of safety, the engine must never exceed the speed. (r.p.m.) indicated on the label.

l) Take care when starting the engine and be sure to follow the user instructions. Never place your hands or feet underneath the deck or into the rear discharge chute while the engine is running.

m) Never lift the rear of the mower while starting the engine or during normal operation.

n) If the blade happens to hit any obstacle, stop the engine at once and remove the spark plug cap. Then get an expert to examine the blade.

Maintenance and storage

a)Make sure that all nuts, bolts, and screws are kept well tightened to keep the mower in a safe operating condition.

b)Never leave the machine with fuel in the tank within an enclosed area where the fuel vapours could reach naked flames or sparks.

c)Allow the engine to cool before storing in any enclosure.

d)Keep the engine, silencer, battery compartment and petrol tank free from grass, leaves and excess lubricant, in order to reduce the danger of fire.

e)Frequently check the grass catcher for wear or deterioration


f)For safety reasons, be sure to replace worn-out or damaged parts in due time.

g)If the fuel tank has to be drained, it is essential that this be done outdoor.

h)Assemble the blades following the corresponding instructions and use only blades bearing the maker's name or the trademark of the manufacturer or supplier and marked with the reference number.

i)To protect hands during disassembly or assembly of the blades, it is absolutely essential to wear suitable protective gloves.

MAINTENANCE




Caution! *Switch off the motor and disconnect the spark plug before undertaking any maintenance work.*

- For a four stroke engine, check the oil level and change the oil when dirty. For further explanation, see ENGINE INSTRUCTION BOOK.
- Frequently check the mower and ensure that all grass deposits are removed from beneath the deck.
- Never clean the mower by pouring water over it: this may seriously damage the electric start system.
- Take care, the exhaust muffler may be very hot.
- Frequently remove the wheel screws clean whith petroleum and oil before replacing. Ball bearings must be greased before remounting.
- Frequently check the blade for damage.
- The lawn mower must be checked by a SERVICE DEALER.


BLADE *(starts at page 58)*

T



- To remove the blade (26) unscrew the screw (27).
- Check the conditions of the blade-support (28), the washer (29), the key (30) and the washer (31) and replace any parts which are damaged.
- When reassembling, make sure that the key (30) is correctly seated in the shaft and that the cutting edges face in the direction of the engine rotation. The blade screw (27) must be torqued to 5,34 Kgm (52,4 Nm).

U



- To remove the blade (32) unscrew the two screws (33).
- Check the condition of the blade and replace any parts that are damaged, re-assemble using two screws (33) which must be torqued to 5,34 Kgm (52,4Nm).

V

KIT ELECTRIC STARTING *(starts at page 58)*



- Before starting the motor for the first time, you are advised to keep the battery on charge for 2 to 3 hours.
  If the battery proves to be low during starting, charge it for 24 hours.
  When starting, don't keep trying to start for more than 5 seconds.


BATTERY MAINTENANCE

IMPORTANT

For correct battery maintenance (34), especially in preparation for a long period of inactivity, and for recharging, it is not necessary to remove it from its casing, but to simply proceed as follows:

1) Remove contact (35).
2) Store the battery in a fresh and dry place.
3) Recharge the battery before use at room temperature for 24-36 hours.
4) Restore the contact (35) before use.

BATTERY DISPOSAL




Those batteries marked with a “crossed out waste disposal bin” and bearing the chemical symbol Pb (battery containing lead) are not to be disposed in domestic waste bins.




The user is legally obliged to take the used batteries to special collection points or to return them to the retailer.


A


14
18
1
13
16
11
3
2
12
4
5
9
15
10
6
7
8
3
17
14
18
1
20
13
16
18
1
14
13
19
16


B



A
A
A
B
B
B


C





D1










































D2






















































D3






















































D4





D5

















































E




F




G




H




I




J





K





L




M
13
14
N
18
13
14
O
18
20
13
14


P
14
13
19
18
11
Q
14
13
19
20
18
11
R
S
P
R


S
23
22
24
21
T
30
28
26
29
31
27


U
32
33
V
BATTERY
34
35
BATTERY